



## FIBERGLASS BATTEN ON STUD DETAIL

- NOTE: 1) GAP BETWEEN PANELS TO BE LESS THAN 1/8" 3"=1'-0"
- 2) **MUST** PRE-DRILL AND COUNTERSINK HOLES FOR SCREWS